

**APERTURE TO REDUCE SENSITIVITY TO SAMPLE TILT
IN SMALL SPOTSIZE REFLECTOMETERS**

Inventors: Adam E. Norton

5

TECHNICAL FIELD

This invention relates to optical tools for measuring and evaluating semiconductor wafers. In particular, the present invention relates to methods for reducing the sensitivity of metrology tools to sample tilt present during the measurement process.

10

BACKGROUND OF THE INVENTION

As semiconductor geometries continue to shrink, manufacturers have increasingly turned to optical techniques to perform non-destructive inspection and analysis of semiconductor wafers. Techniques of this type, known generally as optical metrology, operate by illuminating a sample with an incident field (typically referred to as a probe beam) and then detecting and analyzing the reflected energy. Ellipsometry and reflectometry are two examples of commonly used optical techniques. For the specific case of ellipsometry, changes in the polarization state of the probe beam are analyzed. Reflectometry is similar, except that changes in intensity are analyzed.

20

As shown in Figure 1, a typical reflectometer includes an illumination source that creates a monochromatic or polychromatic probe beam. The probe beam is projected by one or more lenses onto the surface of a sample. The sample reflects the probe beam and the reflected probe beam (or a portion of the reflected probe beam) is transported to a detector. The detector transforms the energy it receives into corresponding output signals. A processor analyzes the signals to measure the structure or composition of the sample. Reflectometers are often used to measure film thickness and dimensions of etched lines among other properties on semiconductor wafers. Instruments such as these that are designed to measure small spots on specular samples at near-normal incidence will usually use a microscope objective both to focus illumination onto the sample and to collect the reflected light.

25

30

An issue with this arrangement is that it can cause the measurements to be sensitive to small errors in local sample tilt. This effect is shown in Figures 2 and 3. Figure 2 shows the

typical shape of the pupil of a reflective Schwarzschild microscope objective often used in reflectometers. A cross-section of a portion of a reflectometer containing the objective is shown in Figure 3. Illumination light 302 reflects from beamsplitter 304 and illuminates the entire objective pupil shown schematically as 306. The light that passes through the pupil is shown as the shaded area 308. This light is focused by the objective shown schematically as 310. The light reflects off a small area of the sample 312 and returns through the objective 310 and pupil 306. Light that passes through the left side of the pupil 306 heading towards the sample 312 will return through the right side and vice versa. The returning light arrives at the beamsplitter 304 where a portion is transmitted. It then continues to a detector (not shown) where at least a portion of the light is collected and measured. In the case of the typical symmetric pupil shown in Figure 3, the light returning from the sample 312 has the same width as the opening in the pupil through which it must pass. A problem with this typical arrangement is that small variation in sample tilt will cause an undesired variation in the amount of light collected by the detector and therefore degrade the reproducibility of the measurements.

One effective solution to minimize this sensitivity to sample tilt is to place an aperture in the illumination path before the beamsplitter that has openings smaller than those in the objective pupil. A lens may be used to project this aperture onto the back focal plane of the objective to insure good telecentricity. The main drawback with this approach is that it becomes complicated to accommodate multiple objectives, mounted in a turret for example, that may be used in the instrument. A different aperture may be needed for each one. A fixed aperture in the illumination path may also interfere with other configurations of the instrument. It would be very desirable to have a solution for the tilt sensitivity that did not affect other objectives or instrument configurations.

Another problem that is peculiar to the type of pupil shown in Figure 2 is that the straight "spider arms" that join the central obstruction to the outside diffract light in the vertical and horizontal directions and make it more difficult to measure very small areas on the wafer.

To minimize this type of tilt sensitivity, U.S. Patent No. 5,486,701 and U.S. Patent No. 5,747,813 discloses the use of a fully-reflecting mirror covering half the objective pupil together with an aperture to create a beam of illumination that enters only one half of the

pupil and exits only from the other half where it can be either slightly larger or smaller than the exit opening. This patent does not disclose how the tilt sensitivity might be remedied when a conventional partially reflecting beam splitter is used to direct light down both halves and collect light from both halves.

5 For at least these reasons, a need exists for a method for reducing the sensitivity of Schwarzschild (and other normal incidence) objectives to sample tilt. Methods of this type are particularly relevant for metrology systems that use multiple objectives mounted on a single turret. Preferably, such methods would be retrofittable to existing systems and work in combination with traditional beam splitters (i.e., beam splitter that cover the entire objective
10 pupil).

SUMMARY OF THE INVENTION

The present invention includes an aperture for reducing tilt sensitivity in normal incidence optical metrology. The aperture is formed to include one or more holes and is
15 positioned to partially occlude one-half of the pupil of a normal incidence objective. In use, a probe beam is projected to fill the pupil of the objective. The portion of the incident probe beam that passes through the aperture is reduced in cross-sectional profile. As a result, after reflection by the sample, that portion of the probe beam underfills the non-occluded portion of the pupil. The remaining portion of the incident probe beam (i.e., the portion that passes
20 through the non-occluded portion of the pupil) overfills the occluded pupil upon reflection from the sample. The combination of underfilling and overfilling reduces the sensitivity of the objective to tilting of the sample.

BRIEF DESCRIPTION OF THE DRAWINGS

25 Figure 1 shows a prior art optical metrology system.

 Figure 2 is a schematic representation of the pupil of a prior art objective.

 Figure 3 is a schematic showing the path traveled by a probe beam as it is first focused by an objective onto a sample and then collected by the objective after reflection by the sample surface.

Figure 4A shows an aperture for normal incidence Schwarzschild objectives as provided by an embodiment of the present invention.

Figure 4B shows an aperture for normal incidence refractive objectives as provided by an embodiment of the present invention.

5 Figure 5A shows attenuation of an incident probe beam within an optical metrology system by an aperture as provided by an embodiment of the present invention.

Figure 5B shows attenuation of a reflected probe beam within an optical metrology system by an aperture as provided by an embodiment of the present invention.

10 Figure 6 shows a reflectometer implemented using an aperture as provided by an embodiment of the present invention.

DETAILED DESCRIPTION OF THE PREFERRED EMBODIMENTS

The present invention includes an aperture for reducing tilt sensitivity in normal incidence optical metrology. Figure 4A shows an implementation of the aperture 402
15 superimposed over a pupil 404 of a Schwarzschild objective. Aperture 402 is positioned to partially occlude one-half of pupil 404 and includes two holes. Each hole is slightly smaller than one of the non-obstructed quadrants of the Schwarzschild objective. The holes are internally radiused to minimize straight lines and sharp corners to help minimize the amount of diffracted light.

20 Figure 4B shows a second implementation of the aperture 402 superimposed over the pupil of a conventional objective (i.e., an objective without spiders or a central obstruction). Aperture 402 includes a single hole shaped as a compromise between minimizing diffraction effects and maximizing the total transmitted light. The optimal shape for the aperture for minimizing diffraction and reducing tilt sensitivity would be a circle having a diameter
25 slightly smaller than half the diameter of the objective pupil.

Figure 5A shows the placement of aperture 402 between an objective 502 and a sample 504. This placement is unlike traditional apertures, which are typically placed in the back focal plane to avoid field vignetting. In this case, because of the particular geometry of aperture 402 and the small field size, vignetting is not a problem. It should also be noted that
30 aperture 402, when appropriately sized may be located anywhere between sample 504 and the preceding beam splitter (not shown).

Figure 5A shows only the light that enters the right-hand side of objective 502. This light is focused by objective 502 onto a sample 504. The beam reflecting from sample 504 falls on the aperture 402 which obstructs the outside-edges of the beam. The remainder of the beam continues on through aperture 402 and past the left side of objective 502 without being further obstructed. In Figure 5A, if sample 504 tilts slightly, the reflected beam will shift on the aperture 402 but (assuming that the beam is uniform), the amount of light passing through the aperture 402 will remain constant.

Figure 5B shows the light entering the left side objective 502 that was omitted for clarity from Figure 5A. This light passes through objective 502 and falls on aperture 402. Aperture 402 attenuates the edges of the incident beam before it reaches sample 504. After being reflected by sample 504, the beam passes through aperture 402 and objective 502 with room to spare. If sample 504 tilts slightly, the beam will shift within objective 502, but will not be further attenuated. In this case the insensitivity to tilt does not depend on the beam uniformity.

As shown in Figure 5A and 5B, aperture 402 effectively reduces beam fluctuations associated with sample tilt. Importantly, by positioning aperture 402 between objective 502 and sample 504, it becomes possible to configure metrology systems to include distinctive apertures for different objectives. In multi-objective configurations, this allows each objective to be paired with an optimally configured aperture. Aperture 402 is easily retrofittable to existing metrology systems and has the additional advantage of reducing diffraction created by spider arm assemblies within Schwarzschild objectives.

Figure 6 shows a reflectometer that includes the aperture provided by the present invention. As shown in Figure 6, the reflectometer includes an illumination source 602 that creates a monochromatic or polychromatic probe beam. The probe beam is collimated by a lens 604 before reaching a beam splitter 606. Beam splitter 606 redirects the probe beam onto the pupil 608 of an objective lens 610. In general, it should be appreciated that pupil 608 is an abstraction shown for purposes of illustration and is not meant to imply a physical structure. Objective lens 610 may be of any type used in normal incidence reflectometry and may include multiple optical elements. As shown in Figure 6, beam splitter 606 is positioned so that the redirected probe beam fills pupil 608. This is the

preferred implementation where both pupil halves (shown in Figure 5A and 5B) are substantially or even fully illuminated.

Aperture 612 is placed between objective 610 and a sample 614. Aperture may be of the type shown in either Figure 4A or 4B and may be positioned anywhere between beam splitter 606 and sample 614. Sample 614 reflects the probe beam back through objective lens 610 and beam splitter 606 to be focused by a lens 616 onto a detector 618. Detector converts the probe beam into corresponding signals for analysis by processor 620.

The use of aperture 612 makes the reflectometer of Figure 6 less sensitive to sample tilt. This is accomplished while maintaining illumination to both pupil halves to maximize instrument sensitivity.